

## SCOOTER SETTINGS

In order to obey with the different countries traffic legislations, there are 3 speed levels: 25KM/H, 20KM/H, 12KM/H. Also, the scooter has a kick start option (the acceleration will start only after you slide the scooter with your foot first) and cruise control function.

This is the how you set the kick-start, cruise control and speed-limit function:

The cruise control function can be activated/ deactivated following the instructions below:

1. Turn off the scooter
2. Press the brake handle all the way down and with the brake handle pressed like this turn on the scooter
3. Do not release the brake handle.
4. With the brake handle still pressed all the way through, please press the acceleration handle all the way down 2 times.
5. Release both handles.
6. Now the cruise control is activated.
7. To deactivate it please follow the same steps as above.

Using the same procedure as before, there are more functions you can use if you press the acceleration handle (step 4 ) as follows:

- if you press the acceleration handle 2 times --> activate/ deactivate the cruise control function
- if you press the acceleration handle 3 times --> activate/ deactivate the kick start function
- if you press the acceleration handle 4 times --> deactivate the speed limit function
- if you press the acceleration handle 5 times --> activate a maximum speed limit of 25 km/h
- if you press the acceleration handle 6 times --> activate a maximum speed limit of 20 km/h
- if you press the acceleration handle 8 times --> activate a maximum speed limit of 12 km/h